




# VICLEAN APP

The app for your ViClean-I 100 shower-toilet


# GENDER SPECIFIC PROFILE DISPLAY



- 1 Profile Lady Wash
- 2 Profile Rear Wash
- 3 Create other profiles
- 4 Select gender  
Return to gender selection
- 5 Settings



# REMOTE CONTROL DISPLAY



- ① Set nozzle options
- ② Set water temperature
- ③ Adjust pressure of water jet
- ④ Pulsating spray
- ⑤ HarmonicWave spray
- ⑥ Start
- ⑦ Stop
- ⑧ Personalise profile name
- ⑨ Delete profile

