

SIMPLE INSTRUCTIONS

Maro DI600



Cleaning

When deaning function is operating you can control the following functions:

2



REAR/MOVE

Front cleaning

3



FRONT/MOVE

Rear cleaning

1



STOP

Stop cleaning

Tip 1



WATER

Adjust water temperature

Tip 2



PRESSURE-



PRESSURE+

Adjust pressure

Tip 3



NOZZLE FORWARD



NOZZLE BACKWARD

*Water temperature can be regulated at any time.

Drying

4



DRY

Start warm drying

1



STOP

Stop warm drying

Tip 4



DRY

Dry temperature regulator

TIPS



AUTO

Press the button to start full auto function, it will start work from rear cleaning, bidet cleaning, drying.



NOZZLE FORWARD

Press the "nozzle clean" button, auto self-clean begin working; Or you can also clean it manually.



AUTO

For full auto function, there is a button on upper side of the RC*.

It will start from rear cleaning, bidet cleaning, drying and auto flush at the end of this function.

*RC is equal remote control